

Compressible Flows

Dr. Gergely Kristóf
12 November 2014.

Numerical schemes for compressible flows

- We can assume, that the state of a computational element is determined by its neighbors.
- That way, the solution of large algebraic systems can be avoided.
- The price to be paid: acoustic waves need to be resolved, that is, the **time step size is limited**.

Speed of infinitesimal disturbances in still gas

Continuity:
 $A(a - dv)(\rho + d\rho) = a \rho A$
 $a d\rho = \rho dv$

Momentum theorem:
 $\sum \vec{I} = \sum \vec{P}$
 $A \rho a (a - (a - dv)) = A dp$
 $dp = \rho a dv$


Allievi theorem \rightarrow

$$a^2 = \frac{dp}{d\rho} = \sqrt{\gamma RT}$$


in ideal gases

Propagation of small disturbances in subsonic and in supersonic flow

Positions of an object having velocity v at time instants 0, -1, -2 and -3 seconds and also showing the wave fronts started in those instants:




From co-moving (relative) frame of reference



Consequence: more data need to be specified at inlet boundaries and less data at outlet boundaries in supersonic flows.

Nonlinear wave propagation

What if we generate another small disturbance?




$v_2 > a$ because:

- The second wave propagates in a gas flow of dv velocity.
 - The second wave propagates in a gas flow having a higher speed of sound: $p \uparrow \rightarrow T \uparrow \rightarrow a \uparrow$.
- The second wave will catch up to the first wave.

Shock waves

A compression wave is steepening, and finally it becomes a **shock wave**.



Expansion waves behave in the opposite way:



- Treated as a discontinuity (finite jump) of the state variables (p , ρ , T and a).
- Propagates faster than the small disturbances. (Only shock waves can do so.)
- Deceleration of supersonic flows are generally caused by shock waves.
- It is a dissipative process. (Causes head losses.)

Analogy

Hydraulic jump in a sink



Application

Schlieren image of a gun fire




[http://www.phschool.com/science/science_news/articles/revealing_covert_actions.html]

Resonance in a closed pipe



Pipe length: 6.05 m
Diameter: 36 mm
Piston displacement: 50 cm³.

At 29 Hz we measured:



More rapid pressure change in the compression phase can be observed.

1D isentropic flows

Unsteady isentropic flow in a constant cross-section pipe.
Eg. in an exhaust pipe.

Continuity:
$$\frac{\partial \rho}{\partial t} + \frac{\partial(\rho u)}{\partial x} = 0$$

Euler equation:
$$\frac{\partial u}{\partial t} + u \frac{\partial u}{\partial x} = -\frac{1}{\rho} \frac{\partial p}{\partial x}$$

Isentropic relation:
$$\frac{p}{\rho^\gamma} = \frac{p_0}{\rho_0^\gamma}$$

p_0 and ρ_0 are the pressure and density in the reference state.
 p , ρ , u are unknown functions of x and t .

Introduction of the sound speed "a" as a new field variable

Only one state variable can be chosen in isentropic system.
We can use the speed of sound "a" to express the pressure (p) and density (ρ).
Both "u" and "a" do have the dimension of m/s.

$$\frac{p}{\rho^\gamma} = \frac{p_0}{\rho_0^\gamma} \quad \left| \quad a^2 = \frac{\partial p}{\partial \rho} \right|_{s=const.} = \gamma \frac{p}{\rho} = \gamma \rho^{\gamma-1} \frac{p}{\rho^\gamma} = \gamma \frac{p_0}{\rho_0^\gamma} \rho^{\gamma-1}$$

$$\ln(p) - \gamma \ln(\rho) = \ln\left(\frac{p_0}{\rho_0^\gamma}\right) \quad \left| \quad 2 \ln(a) = (\gamma-1) \ln(\rho) + \ln\left(\gamma \frac{p_0}{\rho_0^\gamma}\right)\right.$$

$$\frac{dp}{p} = \gamma \frac{d\rho}{\rho} \quad \left| \quad 2 \frac{da}{a} = (\gamma-1) \frac{d\rho}{\rho}\right.$$

$$\frac{\partial a}{\partial p} = \frac{\gamma-1}{2\gamma} \frac{a}{p} \quad \left| \quad \frac{\partial a}{\partial \rho} = \frac{\gamma-1}{2} \frac{a}{\rho}\right.$$

We reformulate the governing equations

Continuity: $\frac{\partial \rho}{\partial t} \frac{\partial a}{\partial \rho} + u \frac{\partial \rho}{\partial x} \frac{\partial a}{\partial \rho} + \rho \frac{\partial u}{\partial x} \frac{\gamma-1}{2} \frac{a}{\rho} = 0$

$$\frac{\partial a}{\partial t} + u \frac{\partial a}{\partial x} + \frac{\gamma-1}{2} a \frac{\partial u}{\partial x} = 0 \quad (1)$$

Euler equation: $\frac{\partial u}{\partial t} + u \frac{\partial u}{\partial x} + \frac{1}{\rho} \frac{\partial p}{\partial x} \frac{\partial a}{\partial p} \frac{2\gamma}{\gamma-1} \frac{p}{a} = 0$

$$\frac{\gamma-1}{2} \frac{\partial u}{\partial t} + \frac{\gamma-1}{2} u \frac{\partial u}{\partial x} + a \frac{\partial a}{\partial x} = 0 \quad (2)$$

$$\frac{\partial a}{\partial t} + u \frac{\partial a}{\partial x} + \frac{\gamma-1}{2} a \frac{\partial u}{\partial x} = 0 \quad (1)$$

$$\frac{\gamma-1}{2} \frac{\partial u}{\partial t} + \frac{\gamma-1}{2} u \frac{\partial u}{\partial x} + a \frac{\partial a}{\partial x} = 0 \quad (2)$$

$$(1) + (2) \quad \frac{\partial}{\partial t} \left(a + \frac{\gamma-1}{2} u \right) + (u+a) \frac{\partial}{\partial x} \left(a + \frac{\gamma-1}{2} u \right) = 0$$

$$\frac{\partial \alpha}{\partial t} + (u+a) \frac{\partial \alpha}{\partial x} = 0 \quad \alpha = \text{const. in the direction of } C_+ = dx/dt = u+a.$$

$$(1) - (2) \quad \frac{\partial}{\partial t} \left(a - \frac{\gamma-1}{2} u \right) + (u-a) \frac{\partial}{\partial x} \left(a - \frac{\gamma-1}{2} u \right) = 0$$

$$\frac{\partial \beta}{\partial t} + (u-a) \frac{\partial \beta}{\partial x} = 0 \quad \beta = \text{const. in the direction of } C_- = dx/dt = u-a$$

Characteristics

C_+ and C_- are the characteristic directions. α and β are Riemann invariants.


u and a can be expressed in terms of α and β .

$$\left. \begin{aligned} \alpha &= a + \frac{\gamma-1}{2} u \\ \beta &= a - \frac{\gamma-1}{2} u \end{aligned} \right\} \begin{aligned} a &= \frac{\alpha + \beta}{2} \\ u &= \frac{\alpha - \beta}{\gamma-1} \end{aligned}$$

Every field variable can then be expressed in terms of a :

$$\left(\frac{a}{a_0} \right)^2 = \frac{T}{T_0} = \left(\frac{p}{p_0} \right)^{\frac{\gamma-1}{\gamma}} = \left(\frac{\rho}{\rho_0} \right)^{\gamma-1}$$

Numerical solution



$$\begin{aligned} \alpha_3 &= \alpha_1 & \beta_3 &= \beta_2 \\ \rightarrow a_3 &= \frac{\alpha_3 + \beta_3}{2} & u_3 &= \frac{\alpha_3 - \beta_3}{\gamma-1} \end{aligned}$$

$$x_3 - x_1 = 0.5 \left[(u_3 + a_3) + (u_1 + a_1) \right] (t_3 - t_1) + o(\Delta t^2)$$


$$x_3 - x_2 = 0.5 \left[(u_3 - a_3) + (u_2 - a_2) \right] (t_3 - t_2) + o(\Delta t^2)$$

t_3, x_3 can be calculated.

Boundary conditions

Inflow:

T_0, p_0, a_0 are given



the energy equation

$$T_0 = T + \frac{u^2}{2c_p} = \frac{a^2}{\gamma R} + \frac{u^2}{2c_p}$$

$$T_0 = \frac{1}{\gamma R} \left(\frac{\alpha + \beta}{2} \right)^2 + \frac{1}{2c_p} \left(\frac{\alpha - \beta}{\gamma-1} \right)^2$$

Either α or β is already given. (Along the outrunning characteristic curve.) The other quantity can be expressed from the above equation.

Outflow:


$$a_0 = a = \frac{\alpha + \beta}{2}$$

Closed pipe:

$$u = 0 \rightarrow \frac{\alpha - \beta}{\gamma-1} = 0 \rightarrow \alpha = \beta$$

The problems...

- The numerical resolution depends on the actual physical properties, therefore it can become very coarse in some regions.
- The characteristic curves running in the same direction can intersect each other.



Finite volume method

The density based approach.

Continuity: $\frac{\partial \rho}{\partial t} + \frac{\partial \rho u}{\partial x} = 0$


Eq. of motion: $\frac{\partial \rho u}{\partial t} + \frac{\partial (\rho u^2 + p)}{\partial x} = 0$ Equation of state: $p = \rho R T$

Energy eq.: $\frac{\partial \rho e}{\partial t} + \frac{\partial (\rho u e + p u)}{\partial x} = 0$ $e = c_v T + \frac{u^2}{2}$

In vector format: $\frac{\partial \underline{U}}{\partial t} + \frac{\partial \underline{F}}{\partial x} = \underline{Q}$

$$\underline{U} = \begin{bmatrix} \rho \\ \rho u \\ \rho e \end{bmatrix} \quad \underline{F} = \begin{bmatrix} \rho u \\ \rho u^2 + p \\ \rho u e + p u \end{bmatrix} \quad \underline{Q} = \begin{bmatrix} 0 \\ 0 \\ 0 \end{bmatrix}$$

Two step Lax-Wendroff method with second order accuracy:



Step 1:
$$U_{i+1/2}^{n+1/2} = \frac{(U_i^n + U_{i+1}^n)/2 + F_{i+1}^n - F_i^n}{\Delta x} = \frac{Q_i^n + Q_{i+1}^n}{2}$$

When U is known ρ , u and e can be calculated. Eg. $\rho = (\rho u)/u$
p is then obtained from the equation of state.

F and Q values can then be calculated at the time level n+1/2.

Step 2:
$$U_i^{n+1} = U_i^n + \frac{F_{i+1/2}^{n+1/2} - F_{i-1/2}^{n+1/2}}{\Delta x} = \frac{Q_{i-1/2}^{n+1/2} + Q_{i+1/2}^{n+1/2}}{2}$$

This is an explicit time marching scheme. Only conditionally stable. According to the linear stability theory:

$$\Delta t = \sigma \frac{\Delta x}{a + |u|} \quad \sigma \leq 1 \quad \text{Courant number}$$

Strong oscillations can take place in the presence of shockwaves. Fluxes must be corrected by using some upwinding or artificial viscosity.

A similar approach in FLUENT: density based solver + explicit formulation (time integration). The multi step time integration method implemented in FLUENT allows somewhat larger Courant number. (The default value is $\sigma=1$.)

Specification of the boundary conditions:
the method of characteristics can be used at the domain boundaries. (There are other approaches too.)